

# DuPont™ Tedlar®

polyvinyl fluoride film

## General Properties

### Summary of Properties

#### General

Unique properties of DuPont™ Tedlar® polyvinyl fluoride (PVF) film include excellent resistance to weathering, outstanding mechanical properties, and inertness towards a wide variety of chemicals, solvents, and staining agents. General properties are summarized in **Table 1**.

Biaxially oriented Tedlar® is available in clear or pigmented forms in Type 3. Tedlar® contains no plasticizers; hence, it has good aging properties and remains tough and flexible over a broad temperature range.

Tedlar® is supplied with both sides treated for adherability to enable bonding to a wide variety of substrates. Treated surfaces have excellent compatibility with many classes of engineering adhesives, including polyesters, epoxies, urethanes, phenolics, rubbers and pressure-sensitive mastics.

Outdoor weathering tests on Tedlar® pigmented films have been conducted for more than 30 years. The weather resistance, inertness and strength characteristics suggest broad use as a finish for architectural panels. The additional features of excellent hydrolytic stability, high dielectric strength and dielectric constant are of interest to the electrical and photovoltaic industries.

### Physical and Thermal Properties

DuPont™ Tedlar® PVF film is strong, flexible and fatigue-resistant. Its resistance to failure by flexing is outstanding. Tedlar® performs well in temperatures ranging from approximately -72 to 107°C (-98 to 225°F), with intermittent short-term peaking up to 204°C (400°F). Some physical and thermal properties of representative Tedlar® PVF films are summarized in **Table 2**.



**Table 1**  
**General Properties of DuPont™ Tedlar® PVF Films**


	Property	Typical Value	Test Method	Test Condition
<b>PHYSICAL</b>	Bursting Strength	29–65 psi	Mullen, ASTM D-774-67	22°C (72°F)
	Coefficient of Friction (Film/Metal)	0.18–0.21	ASTM D-1894-78	22°C (72°F)
	Density	1.37–1.72 g/cc	ASTM D-1505-68	22°C (72°F)
	Impact Strength	10–20 in lb/mil	Spencer ASTM D-3420-80	22°C (72°F)
	Moisture Absorption	<0.5% for most types	Water immersion	22°C (72°F)
	Water Vapor Transmission	9–57 g/m <sup>2</sup> d	ASTM E-96-E-80	39.5°C, 80% RH
	Refractive Index	1.46 n <sub>D</sub>	ASTM D-542-50 Abbe Refractometer	30°C (86°F)
	Tear Strength			
	Propagated	15–60 g/mil	Elmendorf-ASTM D-1922-67	22°C (72°F)
	Initial (Graves)	260–500 g/mil	ASTM D-1004-66	22°C (72°F)
	Tensile Modulus	300–380 x 10 <sup>3</sup> psi	ASTM D-882-80, Method A	
	Ultimate Tensile Strength	8–16 x 10 <sup>3</sup> psi	100% elong./min–Instron ASTM D-882-80, Method A	22°C (72°F)
	Ultimate Elongation	90–250%	100% elong./min–Instron ASTM D-882-80, Method A	22°C (72°F)
Ultimate Yield	6000–4900 psi	100% elong./min–Instron ASTM D-882-80, Method A	22°C (72°F)	
<b>CHEMICAL</b>	Chemical Resistance	No visible effect	1 yr immersion in Acids Bases Solvents	25°C (77°F) 25°C (77°F) 25°C (77°F)
		Strength and appearance not affected	2 hr immersion in Acids Bases Solvents	Boiling Boiling Boiling
			Soil Burial—5 yr	—
	Gas Permeability			
	Carbon Dioxide	11.1 cc/(100in <sup>2</sup> )(24 hr)(atm)(mil)	ASTM D-1434-75	24°C (75°F)
	Helium	150 cc/(100in <sup>2</sup> )(24 hr)(atm)(mil)	ASTM D-1434-75	24°C (75°F)
	Hydrogen	58.1 cc/(100in <sup>2</sup> )(24 hr)(atm)(mil)	ASTM D-1434-75	24°C (75°F)
	Nitrogen	0.25 cc/(100in <sup>2</sup> )(24 hr)(atm)(mil)	ASTM D-1434-75	24°C (75°F)
	Oxygen	3.2 cc/(100in <sup>2</sup> )(24 hr)(atm)(mil)	ASTM D-3985-80	24°C (75°F)
	Vapor Permeability (at part. press. or vapor at given temp.)			
	Acetic Acid	45 g/(100m <sup>2</sup> )(hr)(mil)	ASTM E-96-80, modified	24°C (75°F)
	Acetone	10,000 g/(100m <sup>2</sup> )(hr)(mil)	ASTM E-96-80, modified	24°C (75°F)
	Benzene	90 g/(100m <sup>2</sup> )(hr)(mil)	ASTM E-96-80, modified	24°C (75°F)
	Carbon Tetrachloride	50 g/(100m <sup>2</sup> )(hr)(mil)	ASTM E-96-80, modified	24°C (75°F)
	Ethyl Acetate	1000 g/(100m <sup>2</sup> )(hr)(mil)	ASTM E-96-80, modified	24°C (75°F)
	Ethyl Alcohol	35 g/(100m <sup>2</sup> )(hr)(mil)	ASTM E-96-80, modified	24°C (75°F)
	Hexane	55 g/(100m <sup>2</sup> )(hr)(mil)	ASTM E-96-80, modified	24°C (75°F)
Weatherability	Excellent	Florida exposure	Facing South at 45° to horizontal	
<b>THERMAL</b>	Aging	3000 hr	Circulating Air Oven	150°C (302°F)
	Heat Sealability	Some varieties—see Bulletin TD-14		
	Linear Coefficient of Expansion	2.8 x 10 <sup>-5</sup> in/in/°F		
	Shrinkage (Type 2) MD and TD	4% at 130°C (266°F)	Air Oven, 30 min	
	(Type 3) TD only	4% at 170°C (338°F)	Air Oven, 30 min	
	(Type 4) TD only	2.5% at 170°C (338°F)	Air Oven, 30 min	
Temperature Range				
Continuous Use	-72 to 107°C (-98 to 225°F)			
Short Cycles or Release (1-2 hr)	up to 175°C (350°F)			
Zero Strength	260 to 300°C (500 to 570°F)	Hot Bar		
<b>ELECTRICAL</b>	Corona Endurance (hr)	TTR20SG4      TWH20BS3 2.5              6.2	ASTM Suggested T method	60 cPs, 1000 V/mil
	Dielectric Constant	8.5              11.0	ASTM D-150-81	1 Kc at 22°C (72°F)
	Dielectric Strength (kV/mil)	3.4              3.5	ASTM D-150-81	60 cPs, kV/mil
	Dissipation Factor (%)	1.6              1.4	ASTM D-150-81	1000 cPs, 22°C (72°F)
		2.7              1.7	ASTM D-150-81	1000 cPs, 70°C (158°F)
		4.2              3.4	ASTM D-150-81	10 Kc, 22°C (72°F)
		2.1              1.6	ASTM D-150-81	10 Kc, 70°C (158°F)
	Volume Resistivity (ohm.cm)	4 x 10 <sup>13</sup> 7 x 10 <sup>14</sup>	ASTM D-257-78	22°C (72°F)
		2 x 10 <sup>10</sup> 1.5 x 10 <sup>11</sup>	ASTM D-257-78	100°C (212°F)

**Table 2**  
**Typical Properties of Tedlar® PVF Films**


Description		1.0 mil UV Screening Transparent Type 3	1.0 mil Transparent Type 3	1.5 mil Low Gloss White Type 3	2.0 mil Satin White Type 3	
Designation	Units	TUT10BG3	TTR10BG3	TWH15BL3	TWH20BS3	Test Method
<b>Physical Properties</b>						
Area Factor	ft <sup>2</sup> /lb m <sup>2</sup> /kg	140 28.7	140 28.7	87 17.8	60 12.3	
Ultimate Tensile Strength, Min. (MD)	kpsi MPa	13 90	13 90	8 55	9 62	Instron ASTM D-882-80 Method A—100%/min
Tensile Modulus (MD)	kpsi MPa	310 2,138	301 2,075	305 2,103	385 2,655	Instron ASTM D-882-80 Method A—100%/min
Ultimate Elongation, Min. (MD)	%	95	95	90	110	Instron ASTM D-882-80 Method A—100%/min
Bursting Strength	psi/mil MPa/m	56.9 15.446	48.1 13,057	28.9 7,845	>34.7 >9,420	Mullen ASTM-D-774-67 (1971)
Tear Strength— Propagating (MD)	g/mil kN/m	17.1 6.6	19.2 7.4	23.1 8.9	46.2 17.8	Elmendorf ASTM-D-1922-67 (1978)
Tear Strength— Propagating (TD)	g/mil kN/m	19.0 7.3	17.4 6.7	18.6 7.2	26.6 10.3	Elmendorf ASTM-D-1922-67 (1978)
Tear Strength— Initial (MD)	g/mil kN/m	373 144	423 163	333 129	506 195	Graves ASTM-D-1004-66 (1981)
Tear Strength— Initial (TD)	g/mil kN/m	435 168	478 185	264 102	377 146	Graves ASTM-D-1004-66 (1981)
Impact Strength	in lb/mil kJ/m	20.3 90.3	17.5 77.9	9.6 42.7	16.1 71.6	Spencer ASTM D-3420-80
Specific Gravity	—	1.37	1.39	1.46	1.71	ASTM D-1505-68 (1979)
Coefficient of Friction Film/Metal	—	0.21	0.21	0.18	0.18	ASTM D-1894-78
Coefficient of Abrasion	—	—	—	385	—	ASTM D-658-81
Moisture Absorption	%	<0.5	<0.5	<0.5	<0.5	ASTM D-570-81
Moisture Vapor Transmission	g/m <sup>2</sup> d	30.1	30.2	24.5	16.9	ASTM E-96E-80
<b>Thermal Properties</b>						
Aging in Air	Hours to embrittlement	3,000	3,000	3,000	3,000	Oven at 300°F
Heat Sealability	—	—	Some varieties—see Bulletin TD-14			
Linear Coefficient of Expansion (MD)	m/mK	7.8 x 10 <sup>-5</sup>	8.8 x 10 <sup>-5</sup>	6.7 x 10 <sup>-5</sup>	9.7 x 10 <sup>-5</sup>	D-696-79 (at 50–70°C)
Linear Coefficient of Expansion (TD)	m/mK	8.1 x 10 <sup>-5</sup>	7.1 x 10 <sup>-5</sup>	8.0 x 10 <sup>-5</sup>	8.3 x 10 <sup>-5</sup>	D-696-79 (at 50–70°C)
Shrinkage, Max. (TD)	% at °C	6 at 150	5 at 170	5 at 170	5 at 170	ASTM D-1204-78
Specific Heat	cal/g °C kJ/kg K	0.42 1.76	0.24 1.01	0.26 1.09	0.25 1.05	DuPont 990 Thermal Analyzer

## Physical Properties vs. Temperature


### Tensile Strength



### Elongation



### Tensile Modulus




\*DuPont pneumatic tester


## Hydrolytic Stability

DuPont<sup>™</sup> Tedlar<sup>®</sup> PVF film has excellent resistance to hydrolysis. Strength, yield stress, and elongation are not measurably affected after 60 hr exposure in 85 psig steam 163<sup>°</sup>C (325<sup>°</sup>F).


### Flex Life



### Impact Strength\*




### Elongation




## Thermal Aging


### Tensile Strength




### Elongation



### Impact Strength\*



### Flex Life



[www.tedlar.com](http://www.tedlar.com)

Copyright © 2011 DuPont or its affiliates. All rights reserved. The DuPont Oval Logo, DuPont<sup>™</sup>, The miracles of science<sup>™</sup>, and Tedlar<sup>®</sup>, are registered trademarks or trademarks of E. I. du Pont de Nemours and Company or its affiliates.

NO PART OF THIS MATERIAL MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM OR TRANSMITTED IN ANY FORM OR BY ANY MEANS ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF DUPONT.

The information set forth herein is furnished free of charge and is based on technical data that DuPont believes to be reliable. It is intended for use by persons having technical skill, at their own discretion and risk. The handling precaution information contained herein is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards. Because conditions of product use are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any material, evaluation of any compound under end-use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate under or a recommendation to infringe any patents.

CAUTION: Do not use in medical applications involving permanent implantation in the human body or contact with internal body fluids or tissues. For other medical applications, see "DuPont Medical Caution Statement," H-50102.

